

PROCEDURE FOR FIRE HYDRANT ABANDONMENT

- 1 CLOSE VALVE TO HYDRANT
- REMOVE VALVE BOX AND FILL RISER WITH CLEAN SAND, JET SAND BACKFILL HOLE WITH A.C. PATCH.
- 3 REMOVE, SALVAGE AND DELIVER HYDRANT TO CITY OF MENLO PARK CORPORATION YARD
- REMOVE 152mm(6") SNAP RING AND CUT BURY 305mm(12") BELOW EXISTING GRADE. LINE SHOULD BE CAPPED & CONCRETE KICKER SHOULD BE PLACED TO PREVENT CAP FROM BLOWING OFF WHEN VALVE IS OPENED
- FILL BURY WITH SAND TO CUT RIM. JET SAND; THEN FILL 12 ± REMAINER WITH CLASS "B" CONCRETE OR OTHER MATERIAL TO MATCH EXISTING GROUND SURFACE.

All units are in metric

Non-metric units are in brackets

ACAD FILENAME:HYDRANT

